

P.O. Box 220 * 16024 Hwy 431 Headland AL 36345 (334)-693-3318 (800)-654-8030 Fax (334)-693-5416 www.RushingEnterprises.com

COLD WATER WASHING OPERATING INSTRUCTIONS

- 1. Turn on water supply if applicable.
- 2. Move pump switch to "ON" position.
- 3. Pull Trigger, if a steady stream of water at pressure does not flow from wand within a few seconds **IMMEDIATELY** turn switch to **"OFF"** position. Have a professional service tech correct the problem or contact your Rushing Enterprises technical support team for assistance.
- 4. When a steady stream of water at pressure flows from the wand, turn selector switch to "CHEMICAL" position.
- Starting at the bottom of the vehicle and working your way to the top, apply chemical to the entire surface avoiding the cleaning solution from drying.
- 6. Turn selector switch to the "RINSE" position. Allow hose to clear of all chemicals.
- 7. Start at the top of the vehicle and working your way to the bottom, rinse the entire surface of the vehicle.

SHUTTING DOWN

- 1. Move pump switch to "**OFF**" position.
- 2. Pull trigger to release pressure on the hose and wand.
- 3. Turn off water supply if applicable.